

PEDAL

32 CONTRA VIOLONE
16 DIAPASON
16 BOURDON
16 LIEBLICH GEDECKT (SW)
16 VIOLONE
8 OCTAVE
8 FLUTE
4 CHORALBASS
MIXTURE IV
32 CONTRA POSAUNE
16 POSAUNE
16 WALDHORN (SW)
8 TROMPETE
4 CLARION
GENISYS VOICE 1
GENISYS VOICE 2

SWELL

16 LIEBLICH GEDECKT
8 GEDECKT
8 VIOLA POMPOSA
8 FLUTE CELESTE II
8 VIOLA CELESTE
4 OCTAVE GEIGEN
4 TRAVERSE FLUTE
2-2/3 NASARD
2 PICCOLO
1-3/5 TIERCE
FOURNITURE IV
16 WALDHORN
8 FESTIVAL TRUMPET (NC)
8 FRENCH TRUMPET
8 OBOE
CELESTA
TREMULANT
16 SWELL
SWELL UNISON OFF
4 SWELL
GENISYS VOICE 3
GENISYS VOICE 4

GREAT

16 VIOLONE
8 DIAPASON
8 HARMONIC FLUTE
8 VIOLA POMPOSA (SW)
8 FLUTE CELESTE II (SW)
4 OCTAVE
4 SPITZFLÖTE
2 FIFTEENTH
MIXTURE IV
CYMBALE III
8 FESTIVAL TRUMPET (NC)
8 TROMBA
8 KRUMMHORN
CHIMES
CELESTA (SW)
TREMULANT
GENISYS VOICE 5
GENISYS VOICE 6
MELODY COUPLER
BASS COUPLER

COUPLERS

8 GREAT TO PEDAL
8 SWELL TO PEDAL
4 SWELL TO PEDAL
16 SWELL TO GREAT
8 SWELL TO GREAT
4 SWELL TO GREAT

GENERAL

GENISYS VOICES COUPLER
TREMULANTS FULL
ALTERNATE TUNING
SWELL TO ANTIPH.
SWELL MAIN OFF
GT-PD TO ANTIPH.
GT-PD MAIN OFF

MIDI

MIDI ON PEDAL
MIDI ON SWELL
MIDI ON GREAT