

Schlicker

PEDAL

32 UNTERSATZ
16 PRINCIPAL
16 SUBBASS
16 LIEBLICH GEDECKT (SW)
8 OCTAVE
8 METALGEDECKT
4 CHORALBASS
RAUSCHPFEIFE III
16 FAGOTT
4 CLARION
GENISYS VOICE
GENISYS VOICE
GREAT TO PEDAL
SWELL TO PEDAL

SWELL

8 ROHRFLOETE
8 SALICIONAL
8 VOIX CELESTE
4 GEMSHORN
4 ROHRFLOETE
2-2/3 NASAT
2 NACHTHORN
1-3/5 TERZ
MIXTURE IV
16 DULZIAN
8 TROMPETE
8 OBOE-SCHALMEI
TREMULANT
CELESTA
SWELL UNISON OFF
GENISYS VOICE 3
GENISYS VOICE 4

GREAT

16 GEMSHORN
8 PRINCIPAL
8 KUPFER GEDECKT
8 FLUTE DOLCE CELESTE II (SW)
4 OCTAVE
4 KOPPELFLOETE
2 PRINCIPAL
MIXTURE IV-V
8 TROMPETE
TREMULANT
CHIMES
GENISYS VOICE 5
GENISYS VOICE 6
SWELL TO GREAT

GENERAL

BASS COUPLER
MELODY COUPLER
ALTERNATE TUNING
TREMULANTS FULL
GENISYS VOICES COUPLER
MAIN ORGAN OFF
ANTIPHONAL ORGAN ON

MIDI

MIDI ON PEDAL
MIDI ON SWELL
MIDI ON GREAT